Tel: 01455 450645

eKoWeld@Outlook.com



Turn off the gas supply on the bottle.



Press trigger to release pressure in the hose.



Remove the hose from the bottle.



Fit the eKonoMizer directly onto the gas bottle.



Attach the flow-meter to the eKonoMizer.



Connect the hose to the bottom of the flow-meter.



Turn your output pressure to 75 PSI or 5 BAR

Set your flowmeter: Typically 6 - 11 Litres Per Minute